

easymount.®



ASSEMBLY INSTRUCTIONS


Thank you for purchasing the Easymount Laminator, the stand and laminator are inside the crate below.

Unscrew all screws on the top of the crate:



Remove the top and remove all bolts from the base.

Attached to the crate lid you should have the following parts:



Remove all parts from the crate lid and dispose of the packaging. Attached to the crate base you should have the following parts:

Easymount Laminator



Right mandrel support [inc screws]

Stand swing out arm




Stand bottom support beams



Media feeding brackets

Easymount accessories box

Open the Easymount accessories box and remove the screws. Using 2 x Stand Bolts secure the 2 x Bottom Support Beams to the Left Stand Frame and place the Centre Support beam in the Centre Slots.



Put the Right Stand Frame in position and slide in the bottom support beams and centre support beam.



Secure all beams using the bolts supplied.

Secure the Right mandrel Support to the Right Stand Frame using the 4 x small bolts in the picture below.



Keep the 6 x bolts safe in the photo, until you have un-crated the Laminator.


Fit the Stand Base Plate on the lower cross members.




Attach the Stand Swing Arm on the Left Stand Frame using the 6 bolts from previous page.



Remove Both Side Covers, Handle and Rubber Support for the Quartz Heating Element. Insert Quartz Heating Element and Re-attach the Blue Rubber Support




Remove the Green Insulator shown on previous page and attach the terminal to the element on both ends.




Please note when attaching the terminal place one washer either side, spring washer and nut to follow. Once tightened secure the white insulator to the end of the element as shown in the above picture.

Inside the Accessory box you will find 2 x Large knurled knobs please screw these into the base of the laminator to the stand on either side of the laminator, these lock the machine and stand together.



Locking Screw



Move the laminator to where the machine will be situated, please note all 4 wheels must be on a level floor for the roller pressure to be level.

To check the roller pressure, place a small piece of card in the centre of the roller and lower the roller down. Once in the down position check the gap in between the rollers on the left and right, these should be the same, if not please see the next page.


If the rollers are level, please put the side covers back onto the laminator, once done you can put the roller pressure hand wheel and key in place and secure using the bolt provided.




In the accessory box, you will Find a Handle please secure this to the roller pressure hand wheel.

Easymount: Adjustment of Roller Gap & Pressure

Using a 2.5mm Allen-key undo the 6 screws to take the left side panel of the machine.



Remove the screw and large washer above.




Untighten the screw above to loosen the bevelled gear.



Take off the bevelled gear.

Rotate the pressure regulating shaft to make the upper roller rise slightly. Conduct visual observation and measure the gap between left and right sides of upper and lower rollers. If

the left gap is larger, rotate the gear in the below picture (when rotating clockwise, the roller rises; when rotating anticlockwise the roller declines, each tooth will change the height of 0.02mm) rotate the gear until the roller declines to the height required.



Once the rollers are set, follow the instructions in reverse to put the machine back together.